

**Augment Automotive Technical Manual**


Title: AugTronic Wasted Spark Manual

Document Number: AUG/MAN/008

Version: 002

Author: Tom Barker

Date: 12 July 2017



*Note: Only early dash 944 models required the 100 ohm resistor as oval dash cars have a separate RPM output from the ECU to the dashboard.*

## NOTES:

- Coil pack must be cleanly earthed to engine block via mounting bolts or additional grounding wire.
- +12V supply can be taken from existing +12V feed to standard ignition coil. (Usually black).
- Connector earth (pin 4) should go to the bulkhead as this requires DME ground for coil pack trigger signals.
- For early dash cars the RPM Counter on vehicle dash to function the DME trigger wire (Usually green) must be disconnected from coil negative and connected via 100 ohm resistor to the +12V of the coil.
- The green DME coil trigger wire must NOT be left connected to the standard ignition coil.
- DME A + DME B are trigger signals from Augtronic DME (If these are swapped over engine may backfire when cranking!).

## Wasted Spark Connector on DME

